




Reliability & Satisfaction

Wiring Diagram Junction Box Style (Type -10)



Note: Removing the Connector Clip will re-configure the box for two separate terminals.